SOLENOID

ACCESSORIES

INJECTA
the perfect dosing

Index

01 Multifunction valve

02 0/10 bar adjustable back-pressure valve

03 Removable injection valve

04 Air bleed valve

05 Flow sensor

06 Base mounting bracket

07 Priming Aid

08 Atomizer

09 Level probe with support included

10 Polyethylene tanks

11 PVC support plate for tanks and open top containment tanks


12 Foot filter with check valve

13 Foot filter

14 Injection valve

15 Injection valve: exploded view drawing

Multifunction Valve



Ajustable 0/10bar back-pressure valve

Back-pressure adjustment screw

Tube connection
4x6 or 8x 12


PVC valve head



0/10bar extractable injection valve



Degassing Head



Discharge valve

Epdm or Fpm seals


PVDF pump head suitable for Athena 1/2/3

Relief output

Relief regulation valve

Suction valve

Flow Sensor


Outlet flow
PVC body pump
Sensitivity adjustment screw
Connection for pumps series 1/2/3/4
Valvola di aspirazione
Inlet flow

Mounting bracket

Materials: PP and fiberglass, compatible with Athena and Hydra Series

Fixing screws included

Fixing base



Priming Aid



Filler cap

Wall mounting bracket

PVC body


Suction of the product from the tank

Suction from the dosing pump



Fixing screws included


Atomizer



Level probe with support





Polyethylene tanks



Pvc support plates and open top containment tanks


PVC support plates for tanks from 100 to 1000 lt






Open top containment tanks, from 100 to 1000 lt


Foot filter with check valve



Foot filter: exploded view drawing



Injection Valve



Injection valve: exploded view drawing



Adaptor and rubber washer

FPM or EPDM seals

Connection ½" and ⅜"

Ceramic valve

Hastelloy spring

Removable valve container

injecta.com

INJECTA
the perfect dosing